

KOHLER® Roughing-In

K-T13492, K-T13493, K-T98762
KELSTON®
BATH & SHOWER TRIM SET

Product Information

Applicable product*:	
Bath & shower trim set, with 1/2" NPT threaded or slip-fit diverter spout (shown)	K-T13492-4
Shower only trim set	K-T13493-4
Valve only trim	K-T98762-4
Required accessories:	
Rite-Temp valve OR	K-304-*
HiFlow Rite-Temp valve with stops	K-2971-KS
* For a complete listing of all the Rite-Temp valves, refer to the K-304-* Specification Sheet or Roughing-In sheet.	
Optional accessories:	
HiFlow Rite-Temp® thin wall installation kit	88526
HiFlow Rite-Temp thick wall installation kit	1073881

Installation Notes

Install the valve trim according to the installation guide.

Install the Rite-Temp valve according to the installation guide.

NOTICE: Risk of product damage. Long screws, for installing trim, can damage the K-2971-KS valve. Consult the trim installation guide to verify if the thin wall installation kit (88526) is needed.

Avoid cross-flow conditions. Do not install a shut-off device on either valve outlet.

Cap the shower outlet if the deck-mounted spout, diverter, or handshower is connected to the spout outlet.

Install a 7" (178 mm) to 18" (457 mm) straight pipe or straight tube with single bath elbow between the valve and the wall-mount spout.

